

OWNER'S MANUAL

2000.4



Introduction	n	3
Features		3
Package co	ontents	3
Safety instr	uctions	4
Technolog	gies	
	DTM	5
	Ultra Compact PCB	5
	Robust Construction	5
	Vibration Absorption Device	6
	Low Battery consumption	6
	Marinization with protection index IP64	6
Assembling	g and Disassembling the Plastic Seals	7
Panels de	scription	
	Audio inputs and controls	8
	Power inputs and audio outputs	9
Electrical D	limensioning	10
Installation	sequence	11
Wiring dia	gram	
	Four channels wiring diagram	12
	Three channels wiring diagram	12
	Two channels wiring diagram	13
Procedure	for setting the gain	13
Crossovers	s set up	14
Technical	specs	
	Parameters	15
	Dimensional data	15

5D INTRODUCTION

DEAR CUSTOMER,

CONGRATULATIONS ON ACQUIRING A PRODUCT WITH THE HIGHEST QUALITY AND TECHNOLOGY!

You have just purchased a **SounDigital** product of the highest technology and quality, so we thank you for your confidence.

SounDigital products are made with raw materials of the highest quality standards, and the most modern processes, equipment and technology are used in their production.

On this manual you will learn about the product, its features and characteristics, in order to obtain the best result and to be able to enjoy your music with **SounDigital** quality and power.

To better understand and take advantage of all the functions of the product and use it safely, read this manual carefully and if you have any questions, consult our support by email info@soundigitalusa.com.

FEATURES

- Resistant to moisture, water splash and dust;
- Compact design;
- Conformal coated circuit board;
- Variable crossover with LP / FULL / HP selector switch;
- High efficiency Class D;
- Robust construction, resistant to vibrations and bumps;
- IP64 Rating.

PACKAGE CONTENTS

- 1 EVOPS Amplifier
- 1 Installation quick guide with warranty card
- 1 Allen wrench 2mm
- 1 Allen wrench 2.5mm
- 1 Allen wrench 3mm
- 1 Soundigital promotional black sticker
- 1 Soundigital promotional white sticker

To prevent injuries to the user or damage to the amplifier, read all safety instructions written on this manual;

If you are insecure about the installation of this equipment, get in touch with our tech support or with a professional specialized in car audio/vessel audio installation;

Before proceeding with the installation of any electric equipment on your vehicle/vessel, unplug the negative (-) terminal of the battery to avoid fires, injuries or damages;

Use your sound system safely. The continuous exposure to sound pressures over 85dB may cause irreversible hearing damage;

This equipment is for use in DC voltage batteries between 12.6 and 14.4 volts. Before installing the equipment, check voltage of the batteries;

Choose a ventilated place to install the amplifier;

Mount the amplifier in a secure way. Avoid mounting it on metallic parts of the vehicle/vessel, because it may cause ground looping (noise);

Make sure that the location chosen for the amplifier installation does not effect the operation of the vehicle/vessel;

Please select a dry location to mount your amplifier. The products are designed to operate in humid environments but the direct contact with water can damage the amplifier.

When passing cables through metallic walls, use rubber O-rings to avoid cable cutting and short-circuits.

Clean the amplifier periodically with brush or dry cloth to assure the thermal efficiency of the heatsink.

This product may reach temperatures over 60°C/140°F. Make sure it is cold before touching it;

Be careful when making holes in the vehicle/vessel. Make sure you are not making holes in the fuel tank, brake lines, boat hull or electrical cables of the vehicle/vessel;


Make sure the cables are properly secured throughout the installation;

Wear gloves, safety glasses and and all necessary PPE during the installation of SounDigital amplifiers.



THIS "WARNING" SIGN ALERTS THE USER OF IMPORTANT INFO. NOT FOLLOWING THIS INSTRUCTIONS MAY CAUSE INJURIES TO THE USER OR DAMAGE TO THE EQUIPMENT.

DYNAMIC THERMAL MENAGEMENT - DTM




The **DTM*** is a dynamic thermal management system which always maintains a high efficiency of the amplifier by accelerating the thermal exchange of electronic components with the heatsink

* Patent. Required

ULTRA COMPACT PCB

An intelligent layout, with great use of the PCB area and the use of modern components with reduced structure guarantee **SounDigital** products a compact design, at the same time robust and with excellent thermal efficiency.




ROBUST CONSTRUCTION

Thinking about the application of power sports, the product has an extremely robust assembly, both the correction points and the layout of the plate were designed to withstand high vibrations, bumps and impacts.

VIBRATION ABSORPTION DEVICE


SounDigital added a new device to the EVOPS products which act like shock absorbers reducing the impact of vibration on the eletronic circuit board, thereby increasing the life and reliability of the amplifiers.



ABSORPTION DEVICE

I - POWER SUPPLY


SounDigital amplifiers are known for their low consumption of battery, and this feature was improved on the **EVOPS Line**. The new **I-POWER SUPPLY** is even more modern, which replaces the old toroidal transformers by a new generation of "E-E" core transformers delivers efficiency above 90% *,ensuring more hours of sound without battery recharge.




*Efficiency measured at power supply only

MARINIZATION WITH PROTECTION INDEX IP64


The product is protected against ingress of dust particles and water droplets from all sides, beyond that, the plate receives a conformal coating treatment to protect the components from moisture.




- 1. Squeeze the assembled Flexible Plastics Seals
- 2. Pull out the Plastics Seals



- 1. Hold the disassembled Flexible Plastics Seals and fit them in their specific housing;
- 2. Each connector has its specific Plastic Seal;
- **3.** Make sure the Flexible Plastics Seals are perfectly fitted.



CH2 Variable crossover control - 45Hz to 850Hz
CH4
CH2 Crossover Switch
CH4 Low Pass - Full - High Pass
1
2 Audio input - RCA connector
3
4
CH2 Variable Gain Control
CH4
"Power ON" LED indicator (Blue)
/C /C /C /C /C



12	-	Negative power supply connector (GND)
13	-	Remote power supply connector (REM)
14	-	Positive power supply connector (+12VDC)
15	CH1	Positive speaker connector
16	СП	Negative speaker connector
17	CH2	Negative speaker connector
18	CH2	Positive speaker connector
19	CL IO	Negative speaker connector
20	CH3	Positive speaker connector
21	CH4	Positive speaker connector
22	C1 14	Negative speaker connector

ELECTRICAL DIMENSIONING

For proper operation of your SounDigital amplifier, you need the proper dimensioning of the electrical system and the cables used.

The table below shows the minimum section of GND cables, +12VDC cables and speaker output cables according to the power generated by the amplifier.

2000 WRMS	POWER CABLE GROUND CABLE	21mm² - 4 AWG
	SPEAKER CABLE	2 x 2mm² - 12 AWG

We recommend the use of ONLY OFC (Oxygen Free Copper) Cables on the installation of our products.




BEFORE PROCEEDING WITH THE INSTALLATION, UNPLUG THE NEGATIVE TERMINAL FROM ALL OF THE BATTERIES, TO AVOID FIRE, DAMAGE TO Warning! THE AMPLIFIER AND THE USER HIMSELF

- ➤ Mount the amplifier in such a way you have access to the connectors;
- ➤ Install the power cables in the vehicle/vessel properly, starting from the battery to the fuse holder or circuit breaker, use the cable with the appropriate size. Make all connections, install fuse holders or circuit breakers, but without placing the fuses or with the circuit breakers in the "Off" position.



THE MAX: DISTANCE FOR THE INSTALLATION OF THE FUSE/CIRCUIT BREAKER IS ONE FOOT (30 CM) AWAY FROM THE BATTERY


- Connect the power cables in to the amplifier, observing the polarity. Connect all the positive cables from the fuse holder or circuit breaker to the positive conector of the amplifier and all the negative power cables from the batteries to the negative connector of the amplifier;
- > The ground cable must be as short as possible and must be connected to the negative connector of battery or vehicle chassis in case of metallic chassis;



- ➤ Install the signal input cables in a proper way, distant from the power cables;
- Connect the RCA or the high signal input cables to the head unit and amplifiers;
- > Install the audio output cables with the appropriate section, distant from the power and audio input cables;
- ➤ Connect the audio output cables to the amplifier and speakers respecting the positive (+) and negative (-) polarities;
- ➤ Install the remote cable with the power cables, using 1.5mm² (15 AWG) cable or thicker;
- ➤ Connect the remote power cable to the amplifier's "REM" terminal at the main unit's remote power output;
- > Before powering the system, verify all the connections and make sure there are no mistakes or short-circuits on the power and ground cables;
- > Reconnect the ground of the batteries;
- ➤ Check if the headunit is turned off and then place the fuses in the fuse holders or switch the circuit breakers on;
- > Turn on the main unit and the amplifier will turn on the "On" LED indicating that it is in operation.

4 CHANNEL WIRING DIAGRAM


See "Audio Inputs" on page 8




^{*} Check the minimum speaker impedance at specs table

3 CHANNEL WIRING DIAGRAM

See "Audio Inputs" on page 8



2 CHANNEL WIRING DIAGRAM



^{*} Check the minimum speaker impedance at specs table

GAIN SETTING


- ➤ Necessary equipament:
- ➤ Digital AC voltmeter;
- ➤ Media with sine wave test tone 60Hz recorded at 0db;
- ➤ Screwdriver 1/8" (for gain set)

Set up procedure

- ➤ This procedure is the same for both gain controls;
- ➤ Turn the gain control all the way down.
- ➤ Disconnect the output cables from the amplifier outputs;
- ➤ Turn off all processing (bass, treble, loudness, EQ, etc.);
- ➤ Set the source unit volume to 3/4 of full volume.
- ➤ Set the source unit's fader control to center position;

- ➤ Set the crossover selector switch in "F"
- ➤ Use a 60Hz sine wave
- ➤ Connect the AC voltmeter to the speaker output connectors of the amplifier. Make sure you test the voltage at the correct connectors (+ and -);
- ➤ Increase the gain control until the target voltage is observed with the voltmeter (see the chart below);
- ➤ Once you have adjusted the amplifier to its correct voltage output, turn off the source unit and reconnect the speaker(s)
- ➤ Download the tracks for set up in https://soundigitalusa.com/tracks-for-setup/

MODEL	STEREO / POWER	BRIDGE / POWER	STEREO OUTPUT VOLTAGE	BRIDGE OUTPUT VOLTAGE
2000.4 ΕVO F5 2 Ω	1Ω/ 500W	2Ω/ 1000W	22.4 V	44.8 V
2000.4 ΕVO F5 4 Ω	2Ω/ 500W	4Ω/ 1000W	31.6 V	63,2 V




"F" All the frequencies are reproduced;


"LP " Set in the variable control on Low Pass Function;

"HP" Set in the variable control on High Pass Function.


➤ Selector switch to "F" position (Full Range): All the frequencies are reproduced.



➤ Selector switch to "HP" - Set in the variable control between 45Hz and 850Hz ("A") where you want to perform the high pass cut filter;




➤ Selector switch to "LP" - Set in the variable control between 45Hz and 850Hz ("B") where you want to perform the low pass cut filter;




PARAMETERS	2000.4 Ε/Ο	2000.4 Ε/Ο
Power RMS Bridge @ 2Ω*	2 X 1000W	N/A
Power RMS Bridge @ 4Ω*	2 X 660W	2 x 1000W
Power RMS @ 1Ω*	4 X 500W	N/A
Power RMS @ 2Ω*	4 X 330W	4 X 500W
Power RMS @ 4Ω*	4 X 217W	4 X 330W
Frequency Response (-3dB)	5Hz ~ 22kHz	5Hz ~ 22kHz
Low Pass filter (12dB/oct)	45Hz ~ 850Hz	45Hz ~ 850Hz
High Pass filter (12dB/oct)	45Hz ~ 850Hz	45Hz ~ 850Hz
Operating Voltage	8V ~ 16V	8V ~ 16V
SNR	90dB	90dB
Input Sensitivity	0.2 ~ 4V	0.2 ~ 4V
Current Draw (Music)	85A	85A
Current Draw (Max)	171A	171A
Total Efficiency	81%	81%
Damping Factor (@100Hz nominal impedance)	200	200
Stereo Minimum Impedance	1Ω	2Ω
Bridge Minimum Impedance	2Ω	4Ω
Fuse (music)	100A	100A
Recommended batery	100Ah	100Ah



DIMENSIONAL DATA











Consumer Technology **Association**









