

OWNER'S MANUAL 400.4 EV/**3 6**

Introduction
Package contents
Safety instructions
Panels description
Audio inputs and controls5
Power inputs and audio outputs6
Installation sequence
Electrical dimensioning
Audio inputs
RCA inputs
Crossovers set up
Wiring diagram
Four channels wiring diagram10
Three channels wiring diagram10
Two channel wiring diagram11
Procedure for setting the Gain
Battery connection diagram
Technical specifications
Parameters
Dimensional data13
Additional Information

Dear Consumer,

Congratulations, you have just acquired a SounDigital product of the highest technology and quality, so we thank you for your trust.

SounDigital products are made with raw materials of the highest quality standards, and the most modern processes, equipment and technology are used in their production.

IMPORTANT INFORMATION

On this manual you will learn about the product, its features and characteristics, in order to obtain the best result and to be able to enjoy your music with SounDigital quality and power.

Read this manual carefully and follow precisely all the information contained therein, these are very important and allow your amplifier to work optimally. If you think it is necessary, please do not hesitate to contact our technical support at the following contact:

info@soundigitalusa.com

PACKAGE CONTENTS

- 01 400.4 EVO6 amplifier
- 01 Quick installation guide with warranty certificate

*Merely illustrative image.

BRIDGE 40

 ${\rm BRID}_{GE}_{4\Omega}$

REM GND

To avoid injury to the user or damage to the amplifier, read all safety instructions written on this manual.





THIS "WARNING" SIGN ALERTS THE USER OF IMPORTANT INFO. NOT FOLLOWING THESE INSTRUCTIONS MAY CAUSE INJURIES TO THE USER OR DAMAGE TO THE EQUIPMENT.



1	СПІ		
2	CH2	Audio inputs – RCA connectors	
З	CH3		
4	CH4		
5	CH1/CH2	Variable Gain control	
6	CH3/CH4	Valiable Gain Control	
7	CH1/CH2	Crossover switch key Low Pass – Full – High Pass	
8	CH3/CH4		
8			



9	Blue	"POWER ON" LED indicador
10	-	Negative power supply connector (GND)
11	-	Positive power supply connector (+12VDC)
12	-	Remote power supply connector (REM)
13	CH4	Positive speaker connector (+)
14	CH4	Negative speaker connector (-)
15	CH3	Positive speaker connector (+)
16	СНЗ	Negative speaker connector (-)
17	CH2	Positive speaker connector (+)
18	CH2	Negative speaker connector (-)
19	CH1	Positive speaker connector (+)
20	CH1	Negative speaker connector (-)



BEFORE PROCEEDING WITH THE INSTALLATION, UNPLUG THE NEGATIVE TERMINAL FROM ALL OF THE BATTERIES, TO AVOID FIRE, DAMAGE TO THE AMPLIFIER AND THE Warning! USER HIMSELF.

- \triangleright Fix the amplifier so that the connectors can be easily accessed;
- Install the power cables in the vehicle properly, starting from the battery to the fuse holder or circuit breaker, use the cable with the appropriate size. Make all connections, install fuse holders or circuit breakers, but without placing the fuses or with the circuit breakers in the "OFF" position;



THE MAXIMUM DISTANCE FOR THE INSTALLATION OF THE FUSE/CIRCUIT BREAKER IS 12 INCHES (30cm) AWAY FROM THE BATTERY.

- ≻ Connect the power cables in to the amplifier, observing the polarity. Connect all the positive cables (+) from the fuse holder or circuit breaker to the positive conector of the amplifier and all the negative power cables from the batteries to the negative connector of the amplifier;
- \triangleright The ground cable must be as short as possible and must be connected to the vehicle chassis and the battery negative;

Remove the paint between the terminal and chassis



- Install the signal input cables in a proper way, distant from the power cables;
- Connect the RCA cables to the head unit and amplifiers;
- Install the audio output cables with the appropriate section, distant from the power and \geq audio input cables;
- \geq Connect the audio output cables to the amplifier and speakers respecting the positive (+) and negative (-) polarities;
- Install the remote cable with the power cables, using 1.5mm² (15 AWG) cable or thicker; \geq
- Connect the remote power cable to the amplifier's "REM" terminal at the main unit's remote \geq power output;
- Before powering the system, verify all the connections and make sure there are no mistakes or short-circuits on the power and ground cables;
- Reconnect the ground of the batteries; \geq
- \geq Check if the head unit is turned off and then place the fuses in the fuse holders or switch the circuit breakers on:
- Turn on the main unit and the amplifier will turn on the "POWER ON" LED indicating that it is \triangleright in operation.



Minimum recommended installation distance between amplifiers*.

1.18in. (30mm)



ELECTRICAL DIMENSIONING

For proper operation of your SounDigital amplifier, you need the proper dimensioning of the electrical system and the cables used.

The table below shows the minimum section of GND cables, +12VDC cables and speaker output cables according to the power generated by the amplifier.

400 WRMS	POWER CABLE (+12VDC) GROUND CABLE (GND)	6mm² (9 AWG)
	SPEAKER CABLE	2 x 1.5mm² (15 AWG)

We recommend the use of only OFC (Oxygen Free Copper) cables on the installation of our products.

Copper-clad aluminum wire (CCAW) must not be used.

AUDIO INPUTS

RCA inputs





All RCA inputs must be connected for the amplifier to work properly. If the signal source is mono type, use "Y" cable at the input.



"F" All the frequencies will be reproduced "LP" Frequencies below 80Hz will be reproduced "HP" Frequencies above 80Hz will be reproduced

> Change the switch to "F" position (Full Range) - All the frequencies will be reproduced as in "Figure 1";



> Change the switch to "HP" position - All frequencies above 80Hz will be reproduced as in "Figure 2";



> Change the switch to "LP" position - All frequencies below 80Hz will be reproduced as in "Figure 3".



4 CHANNELS WIRING DIAGRAM (PER CHANNEL)



3 CHANNELS WIRING DIAGRAM



2 CHANNELS WIRING DIAGRAM (BRIDGE)



GAIN SETTING

Necessary equipament:

- Digital AC voltmeter;
- Media with sine wave test tone 60Hz recorded at 0db.

Set up procedure:

- This procedure is the same for both gain controls;
- > Turn the gain control all the way down;
- Disconnect the output cables from the amplifier outputs;
- Turn off all processing (bass, treble, loudness, EQ, etc.);
- Set the audio player volume to 3/4 of full volume;

- On the audio player, set the fader control to center position;
- > Set the crossover selector switch in "F";
- Use a 60Hz sine wave;
- Connect the AC voltmeter to the speaker output connectors of the amplifier. Make sure you test the voltage at the correct connectors (+ and -);
- Increase the gain control until the target voltage is observed with the voltmeter (see the chart below);
- Once you have adjusted the amplifier to the correct voltage output, turn off the source unit and reconnect the speaker(s).

MODEL	STEREO /	BRIDGE /	STEREO OUTPUT	BRIDGE OUTPUT
	POWER	POWER	VOLTAGE	VOLTAGE
400.4 Εν ጋ5 4Ω	2Ω / 100W	4Ω / 200W	14.14V	28.3V

Download the tracks for set up in https://soundigitalusa.com/tracks-for-set-up/

When necessary the association of one or more battery banks to supply the necessary current to the amplifier, it is recommended to use batteries of the same brand, model, and if possible the same manufacturing lot so that the system has the maximum performance.

For an ideal energy performance, we recommend that all batteries be connected to positive and negative busbars and the busbars connected to the amplifier, as shown in the diagram below:



PARAMETERS	400.4 ενσ 5 4Ω
Power RMS @ 4Ω**	4 x 66W
Power RMS @ 2Ω**	4 x 100W
Power RMS (Bridge) @ 4Ω**	2 × 200W
Power RMS (Bridge) @ 2Ω**	N/A
Frequency Response (-3dB)	8Hz ~ 20kHz
Low Pass filter (12dB/octave)	80Hz
High Pass filter (12dB/octave)	80Hz
Operating Voltage	9V ~ 16V
SNR	94dB
Input Sensitivity (RCA)	0.2V ~ 2V
Current Draw (music)	20A
Current Draw (max.)	40.5A
Total Efficiency	78%
Damping Factor (@100Hz nominal impedance)	200
Power Cable	6mm² (9 AWG)
Speaker Cable	2 x 1.5mm ² (15 AWG)
Recommended Fuse* (music)	25A
Recommended Battery (minimum)	40Ah
*It is mandatory to install the fuse at a maximum distance of 12 inches from the battery.	

**Power at 12.6V @ 60Hz with a maximum THD of 1%.



**POWER RATING ACCORDING TO CTA-2006 INDUSTRY STANDARDS.

DIMENSIONAL DATA



ADDITIONAL INFORMATION

The values presented are based on measurements performed in SounDigital's laboratories. All the equipment used in the assays, tests, measurements and gauging of the technical parameters of SounDigital products were calibrated in certified laboratories, thus ensuring the performance and standard of excellence of the developed products.

The Manufacturing Process may present variations, and the electronic components may also present changes in values in relation to their nominal parameters. Thus, causing small differences between measurements taken. Small variations in the values presented and divulged by SounDigital are recognized.

\triangle

Updates of information made in this document will always be published and made available for consumer consultation, free of charge, on the brand's websites. The user is advised to search for the manual in its latest version when necessary.

The images presented in this document are representative and merely illustrative; therefore, they do not necessarily correspond to the actual product/model.













WWW.SOUNDIGITALUSA.COM



