

OWNER'S MANUAL

1200.1



Introduction	3
Features	3
Package contents	3
Safety instructions	4
Technologies	
DTM [®]	5
Ultra Compact PCB	5
Robust Construction	5
I- Power Supply	5
Full Range	6
Marinization with protection index Ip64	6
Assembling and Disassembling the Plastic Seals	7
Panels description	
Audio inputs and controls	8
Power inputs and audio outputs	9
Electrical Dimensioning	9
Installation sequence	10
Wiring diagram	
Wiring diagram	11
Procedure for setting the gain	12
Crossovers set up	13
Technical specs	
Parameters	14
Dimensional data	14

DEAR CUSTOMER,

CONGRATULATIONS ON ACQUIRING A PRODUCT WITH THE HIGHEST QUALITY AND TECHNOLOGY!

You have just purchased a **SounDigital** product of the highest technology and quality, so we thank you for your confidence.

SounDigital products are made with raw materials of the highest quality standards, and the most modern processes, equipment and technology are used in their production.

On this manual you will learn about the product, its features and characteristics, in order to obtain the best result and to be able to enjoy your music with **SounDigital** quality and power.

To better understand and take advantage of all the functions of the product and use it safely, read this manual carefully and if you have any questions, consult our support by email info@soundigitalusa.com.

FEATURES

- Resistant to moisture, water splash and dust;
- Compact design;
- Conformal coated PCB;
- Variable crossover with LP, FULL and HP selector switch;
- High efficiency Class D;
- Robust construction, resistant to vibrations and bumps;
- IP64 Rating.

PACKAGE CONTENTS

- 01 1200.1 EVOPS Amplifier
- 01 Installation quick guide with warranty card
- 01 Allen wrench 2mm
- 01 Allen wrench 2.5mm
- 01 Allen wrench 3mm
- 01 Promotional sticker

To prevent injuries to the user or damage to the amplifier, read all safety instructions written on this manual;

If you are insecure about the installation of this equipment, get in touch with our tech support or with a professional specialized in car audio/vessel audio installation;

Before proceeding with the installation of any electric equipment on your vehicle/vessel, unplug the negative (-) terminal of the battery to avoid fires, injuries or damages;

Use your sound system safely. The continuous exposure to sound pressures over 85dB may cause irreversible hearing damage;

This equipment is for use in DC voltage batteries between 12.6 and 14.4 volts. Before installing the equipment, check voltage of the batteries;

Choose a ventilated place to install the amplifier;

Mount the amplifier in a secure way. Avoid mounting it on metallic parts of the vehicle/vessel, because it may cause ground looping (noise);

Make sure that the location chosen for the amplifier installation does not effect the operation of the vehicle/vessel;

Please select a dry location to mount your amplifier. The products are designed to operate in humid environments but the direct contact with water can damage the amplifier.

When passing cables through metallic walls, use rubber O-rings to avoid cable cutting and short-circuits.

Clean the amplifier periodically with brush or dry cloth to assure the thermal efficiency of the heatsink.

This product may reach temperatures over 60°C/140°F. Make sure it is cold before touching it;

Be careful when making holes in the vehicle/vessel. Make sure you are not making holes in the fuel tank, brake lines, boat hull or electrical cables of the vehicle/vessel;

Make sure the cables are properly secured throughout the installation;


Wear gloves, safety glasses and and all necessary PPE during the installation of SounDigital amplifiers.



THIS "WARNING" SIGN ALERTS THE USER OF IMPORTANT INFO. NOT FOLLOWING THIS INSTRUCTIONS MAY CAUSE INJURIES TO THE USER OR DAMAGE TO THE EQUIPMENT.

4

DYNAMIC THERMAL MENAGEMENT - DTM®




The **DTM** is a dynamic thermal recovery system which always maintains a high efficiency of the amplifier by accelerating the thermal exchange of electronic components with the heatsink.

* Patent. Required

ULTRA COMPACT PCB

An intelligent layout, with great use of the PCB area and the use of modern components with reduced structure guarantee **SounDigital** products a compact design, at the same time robust and with excellent thermal efficiency.



ROBUST CONSTRUCTION


Thinking about the application of power sports, the product has an extremely robust assembly, both the fixing points and the layout of the PCB were designed to withstand high vibrations, bumps and impacts.

I - POWER SUPPLY

SounDigital amplifiers are known for their low consumption of battery, and this feature was improved on the **EVOPS Line**. The new **I-POWER SUPPLY** is even more modern, which replaces the old toroidal transformers by a new generation of "E-E" core transformers delivers efficiency above 90% *,ensuring more hours of sound without battery recharge.



*Efficiency measured at power supply only




VIBRATION ABSORPTION DEVICE - VAD®

Our VAD® Technology reduces all impact caused by vibration on the electronic circuit board. This can include road vibration and even vibration caused by sound waves, increasing the reliability of our amplifiers.

REDUCED SIZE

The technology used in our amplifiers bring both high performance and power a compact chassis, providing flexible installation solutions for vehicles with limited space.








FULL RANGE

Versatile products that cover the entire audible frequency range, any type of loudspeaker or music program.


MARINIZATION WITH PROTECTION INDEX IP64

The product is protected against ingress of dust particles and water droplets from all sides, beyound that, the PCB receives a conformal coating treatment to protect the components from moisture.







- 1. Squeeze the assembled Flexible Plastics Seals
- 2. Pull out the Plastics Seals



- 1. Hold the disassebled Flexible Plastics Seals and fit them in their specific housing;
- 2. Each connector has its specific Plastic Seal;
- **3.** Make sure the Flexible Plastics Seals are perfectly fitted.



1	Left Channel	Audio input - RCA connectors	
2	Right Channel		
3		Variable Gain control	
4		Low Pass filter on/off switch	
5	-	Variable Low Pass filter control (50Hz ~ 500Hz)	
6	-	Variable Subsonic filter control (5Hz ~ 40Hz)	
7	-	Variable Bass Boost Control 50Hz (0dB ~ +12dB)	
8	Blue	"Power ON" LED indicator	
9	Yellow	"Clip" LED indicator	
10	Red	"Protection" LED indicator	



11	Minimum speaker load allowed (impedance)
12	Negative speaker connector
13	Positive speaker connector
14	Positive power supply connector (+12VDC)
15	Remote power supply connector (REM)
16	Negative power supply connector (GND)

SD

ELECTRICAL DIMENSIONING AND AUDIO INPUTS

ELECTRICAL DIMENSIONING

For proper operation of your SounDigital amplifier, you need the proper dimensioning of the electrical system and the cables used.

The table below shows the minimum section of GND cables, +12VDC cables and speaker output cables according to the power generated by the amplifier.

1200 WRMS	POWER CABLE GROUND CABLE	16mm² - 5 AWG
	SPEAKER CABLE	2 x 1,5mm² - 15 AWG

We recommend the use of ONLY OFC (Oxygen Free Copper) Cables on the installation of our products.




BEFORE PROCEEDING WITH THE INSTALLATION, UNPLUG THE NEGATIVE TERMINAL FROM ALL OF THE BATTERIES, TO AVOID FIRE, DAMAGE TO Warning! THE AMPLIFIER AND THE USER HIMSELF

- Mount the amplifier in such a way you have access to the connectors;
- > Install the power cables in the vehicle/vessel properly, starting from the battery to the fuse holder or circuit breaker, use the cable with the appropriate size. Make all connections, install fuse holders or circuit breakers, but without placing the fuses or with the circuit breakers in the "Off" position.




THE MAX: DISTANCE FOR THE INSTALLATION OF THE FUSE/CIRCUIT BREAKER IS ONE FOOT (30 CM) AWAY FROM THE BATTERY

- > Connect the power cables in to the amplifier, observing the polarity. Connect all the positive cables from the fuse holder or circuit breaker to the positive conector of the amplifier and all the negative power cables from the batteries to the negative connector of the amplifier;
- > The ground cable must be as short as possible and must be connected to the negative connector of battery or vehicle chassis in case of metallic chassis;



- Install the signal input cables in a proper way, distant from the power cables;
- > Connect the RCA or the high signal input cables to the head unit and amplifiers;
- Install the audio output cables with the appropriate section, distant from the power and audio input cables;
- > Connect the audio output cables to the amplifier and speakers respecting the positive (+) and negative (-) polarities;
- > Install the remote cable with the power cables, using 1.5mm² (15 AWG) cable or thicker;
- > Connect the remote power cable to the amplifier's "REM" terminal at the main unit's remote power output (when not using the high level signal inputs);
- > Before powering the system, verify all the connections and make sure there are no mistakes or short-circuits on the power and ground cables;
- Reconnect the ground of the batteries;
- > Check if the headunit is turned off and then place the fuses in the fuse holders or switch the circuit breakers on;
- >Turn on the main unit and the amplifier will turn on the "On" LED indicating that it is in operation.



^{*} Check the minimum speaker impedance at specs table

GAIN SETTING

Necessary equipament:

- ➤ Digital AC voltmeter;
- Media with sine wave test tone 60Hz recorded at 0db;
- Screwdriver 1/8" (for gain set)

Set up procedure

- This procedure is the same for both gain controls;
- > Turn the gain control all the way down.
- Disconnect the output cables from the amplifier outputs;
- Turn off all processing (bass, treble, loudness, EQ, etc.);
- Set the source unit volume to 3/4 of full volume.
- Set the source unit's fader control to center position;

- > Set the Low Pass switch to "OFF";
- > Use a 60 Hz sine wave;
- Connect the AC voltmeter to the speaker output connectors of the amplifier. Make sure you test the voltage at the correct connectors (+ and -);
- Increase the gain control until the target voltage is observed with the voltmeter (see the chart below);
- Once you have adjusted the amplifier to its correct voltage output, turn off the source unit and reconnect the speaker(s)


Download the tracks for set up in https://soundigitalusa.com/tracks-for-set-up/

MODEL	BRIDGE / POWER	BRIDGE OUTPUT VOLTAGE
1200.1EVO P5	4Ω/ 1200W	69,3 V RMS

Using Bass Boost

The Amplifier Bass Boost setting enables the user to boost the sound intensity at low frequencies of the sound system, where boost intensity can be adjusted.

This is a semi-parametric equalizer type circuit with "Q" value for the fixed filter, with an intensity boost adjustment from 0 to + 12dB (16 times), and a central frequency adjustment of the filter in 50Hz, making it versatile for several types of sound systems.



How to Adjust Bass Boost




Reproduce your favorite song and set the boost intensity between 0dB and +12dB at the variable control level according your preference.


How to Adjust the Crossovers



Set in the "SUBSONIC" variable control between 5Hz and 30Hz ("A") where you want to perform the subsonic cut filter;




Set in the "LOW" variable control between 50Hz and 500Hz ("B") where you want to perform the low pass cut filter;




PARAMETERS	1200.1EVO =5 4 Ω
RMS Power @ 4Ω	1200W
RMS Power @ 2Ω	N/A
RMS Power @ 1Ω	N/A
Frequency response	5Hz ~ 25kHz
Subsonic	5Hz ~ 40Hz
Low pass filter	50Hz ~ 500Hz
Bass boost	0dB ~ 12dB @ 50Hz
Operating voltage	8V ~ 16V
SNR	94dB
Input sensitivity	0.2V ~ 4V
Current draw (music)	45,3A
Current draw (Max)	90,6A
Total efficiency	92%
Damping factor	>2000
Fuse (music)*	60A
Minimum Recommended Battery	70Ah

^{*}It is mandatory to install the fuse at a maximum distance of 12 inches from the battery.

DIMENSIONAL DATA



Net Weight: 2.4lb (1.1Kg) Gross Weight: 2.9lb (1.3Kg)





EVO ==



Consumer Technology Association









